

**MP506**

**ISP Programming Tool**

**User Manual**

**(VCOM & HID)**

# Singular Technology Company Limited


File Name: ISP Programming Tool User Manual

Page: 1/5

## Step 0:


Plug a reader to a Windows system and install the driver (see mPos Series Windows Demo User Guide.pdf).

Make sure the device is installed well on system and you can see it in the Device Manager.




For USB HID device, it adopt system's HID driver automatically.

Make sure the device is installed well on system and you can see it in the Device Manager.




## Step 1:

Run program "ISP Programming Tool V1.2 (VCOM&HID).exe"




## Step 2:

Click button "Load File".



## Step 3:

Click button "Connect". If the operation is ok, it will show "Reader Connected!..."



## Step 4:

Click button "Write APROM". It will erase APROM, F/W updating until it's done.

